

ICY



ICY2745IN

## ICY-Net Transceiver


# Installation Manual

## Introduction

The ICY2475IN-Transceiver is on the individual locations the link between the ICY-Net and the equipment present. Through this transceiver every location has its own address. With this address it's possible to communicate with the location itself and within the network with other devices and transceivers. The transceivers operate and function in this network as intersections or nodes.

## Installation

1. Connect the power supply to the first two terminals of the transceiver, as shown in the image. The polarity (plus or minus) is not important.
2. Determine where the transceiver will hang and secure it on the wall. Preferably, only on slots 1 and 2 (see illustration). A screw in the top slot will possibly disrupt the ICY-Net signal.  
Place the Transceiver flat on the wall and in an upright position to ensure an optimal communication with the ICY-Net.
3. Connect the required equipment to the non-polarity port and the non-polarity switch.
4. Place cover that is included on the front of the Transceiver.



© I.C.Y. B.V.  
service@icy.nl  
www.icy.nl