

ICY Timer Thermostat connection to district heating Honeywell VC8015 en VC8615

A resistor has to be connected for the correct operation of the ICY Timer Thermostats (e.g. Clever Thermostats or ICY1845TT).

The resistance has to be 680 ohms, 2 watts. This is supplied with the Clever Thermostat. The resistor should be placed between wires 2 and 3. It is advised to use a wire connector.

